


# USB- $\mu$ PIO




## USB AVR board

- Compact AVR board with Atmel ATmega168-20
- High speed clock frequency 18.432000 MHz
- 100% error free High baud rates
- Screw terminal and pin connections
- 6 pin ISP connector
- Power supply (+5V) via USB or external
- 3 LED: USB power, COM (RxD) , USER (Port B.5; can be disabled)
- SOFT-RESET via DTR signal (can be disabled)
- USB-B connector
- USB chipset: CH341A
- Virtual (RS232-)-COM driver (VCP)
- System requirements: XP, 2000, Vista, WIN 7, 32/64 Bit
- Dimensions: approx. 70 x 45 x 15 mm

## Download

[http://www.abacom-online.de/div/setup\\_usb\\_μPIO.exe](http://www.abacom-online.de/div/setup_usb_μPIO.exe)

## Screw terminals, LED and Jumper



- P1 – ISP connector for programmer
- P2 – USB-B connector
- P3 – Pin strip for Port B, Port D, VREF, RST, VCC, GND (Digital port)
- P4 – Pin strip Port C, VREF, VCC, GND (Digital port und ADC port)



- J1 – Jumper SOFT RST connects RESET(PC6) with DTR signal from CH341A
- J2 – Jumper INTERNAL POWER connects VCC with USB supply voltage
- J3 – Jumper ISP POWER connects VCC to ISP
- J4 – Jumper LED2 ENABLE connects LED2 with PB5

- LED1 – RX indicator (red; Data received from PC)
- LED2 – LED at PB5 (yellow; for user purpose)
- LED3 – USB-Power (green; USB power supplied)

Screw terminals for Port B, Port C and Port D

### Terminal names refer to ATmega168 pin names


(PCINT14/RESET) PC6	1	28	PC5 (ADC5/SCL/PCINT13)
(PCINT16/RXD) PD0	2	27	PC4 (ADC4/SDA/PCINT12)
(PCINT17/TXD) PD1	3	26	PC3 (ADC3/PCINT11)
(PCINT18/INT0) PD2	4	25	PC2 (ADC2/PCINT10)
(PCINT19/OC2B/INT1) PD3	5	24	PC1 (ADC1/PCINT9)
(PCINT20/XCK/T0) PD4	6	23	PC0 (ADC0/PCINT8)
VCC	7	22	GND
GND	8	21	AREF
(PCINT6/XTAL1/TOSC1) PB6	9	20	AVCC
(PCINT7/XTAL2/TOSC2) PB7	10	19	PB5 (SCK/PCINT5)
(PCINT21/OC0B/T1) PD5	11	18	PB4 (MISO/PCINT4)
(PCINT22/OC0A/AIN0) PD6	12	17	PB3 (MOSI/OC2A/PCINT3)
(PCINT23/AIN1) PD7	13	16	PB2 (SS/OC1B/PCINT2)
(PCINT0/CLKO/ICP1) PB0	14	15	PB1 (OC1A/PCINT1)



Dimensions approx. 70 x 45 x 15 mm

**Available accessories:**

- Enclosure (unfinished)
- USB ISP programmer with ISP cable



## Firmware

Terminal use depends on the firmware and is described in the firmware datasheets. The protocol description can be found there as well.

We deliver the board ready-made with one of the following firmware options:

/ **GPIO18** ([http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware\\_GPIO18.pdf](http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware_GPIO18.pdf))

### **I/O interface with 18 general purpose digital I/O lines**

Use the board as general purpose digital IO. Compatible with ProfiLab Expert or make a software of your own.

/ **PWMIO18** ([http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware\\_PWMIO18.pdf](http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware_PWMIO18.pdf))

### **Comfortable interface with 18 general purpose digital I/O lines**

Digital I/O board with additional functions, like PWM, servo, blink / pulse. Compatible with ProfiLab Expert or make a software of your own.

/ **FREQ** ([http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware\\_FREQ.pdf](http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware_FREQ.pdf))

### **9 MHz frequency counter / generator**

A powerful firmware with application software included. Compatible with ProfiLab Expert

/ **INCR3** ([http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware\\_INCR3.pdf](http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware_INCR3.pdf))

### **Three incremental encode inputs**

Reads the position of up to three increment encoders. Compatible with ProfiLab Expert.

/ **TEMP12** ([http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware\\_TEMP12.pdf](http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware_TEMP12.pdf))

### **Temperature system for Dallas DS18B20 sensors**

For use with up to 12x Dallas DS18B20 sensors.

/ **ABADUINO** ([http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware\\_ABADUINO.pdf](http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware_ABADUINO.pdf))

### **BOOTLOADER for Arduino software** (<http://www.arduino.cc/>)

The board is similar to the Arduino USB schematics in parts. The bootloader was modified according to the 18.432 MHz clock frequency. The bootloader source is published and included in the software download. It can be found in the SOFTWARE/ABADUINO folder together with the install instructions.

/ **MCS** ([http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware\\_MCS.pdf](http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware_MCS.pdf))

### **MCS BOOTLOADER (BASCOS AVR)**

BASCOS AVR is your favorite AVR programming language. We equip the board with the MCS bootloader. A ISP programmer is not required as you can upload your programs directly from the BASCOS IDE via USB.

/ **CLEAR** ([http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware\\_CLEAR.pdf](http://www.abacom-online.de/div/FirmwareDocs/UK/Firmware_CLEAR.pdf))

### **not programmed \***

\* ISP programmer necessary

You are experienced in AVR programming and like to flash the chip yourself with your own application.